
Indicators& Display
Rear box lamp
Post box light switch
Horn switch
Four flash switch
Turning switch
Headlight switch
Top light switch
Rear drive lock switch
Electric lift switch
Electric lift
Speed sensor
Gear position sensor
Oil pressure switch
Shift controller
Rear driving light input
Rear reversing light input
Right turn light input
Right rear reversing light
Right rear turn light
Right rear driving light
Right rear braking light
Braking light input
Left rear driving light
Left rear braking light
Left rear turn light
Reversing lamp input
Left rear reversing light
Rear license lamp input
Rear license light
Rear drive lock
Rear axle
Seat heating
Connection with magneto
Top light
Headlight
Right front turning light
Left front turning light
Reading lamp
Footboard lamp
Starting motor
Starting relay
Seat heating L
Seat heating R
EFI relay
Fan relay
Oil pump relay
Reversing relay
Accessory relay
Light relay
Four turn two relay
Four turn one relay
Fan 1
Fan 2
Water temperature sensor
The signal wire of power-assisted steering
Electric lock
One button start
Battery
Safety belt
Parking brake switch
Fuel pump assembly
Flash apparatus
Rear drive controller
Engine wire interface
Tie wire 2Black
Horn
Foot brake switch
Stabilized rectifier
The Electric machinery of 2/4WD
2/4WD changeover switch
4WD lock indicator
Negative electrode